

5.1 Maintenance Schedule

Observe the following maintenance schedule. This maintenance schedule is applied to tractors which are operated under normal conditions. When your tractor is frequently operated in muddy places, greasing must be carried out more frequently and when the tractor is often operated in dusty places, clean the air cleaner element and fuel filter more frequently. Extra servicing must be carried out according to particular situation.

Parameters	1st Service 50 Hours	2nd Service 250 Hours	3rd Service 500 Hours	4th Service 750 Hours	5th Service 1000 Hours	6th Service 1250 Hours	7th Service 1500 Hours
General							
Washing	W	W	W	W	W	W	W
Greasing	G	G	G	G	G	G	G
Re-tighten All Fasteners	СТ	СТ	СТ	СТ	СТ	СТ	СТ
Rear View Mirror Holder	СТ	СТ	СТ	СТ	СТ	СТ	СТ
Engine							
Engine Oil	R	R	R	R	R	R	R
Engine Oil Filter	R	R	R	R	R	R	R
Tappet Clearance	CA	CA	CA	CA	СА	CA	СА
Fuel Filter Element	R	R	R	R	R	R	R
Fan Belt Tension	СТ	СТ	СТ	СТ	СТ	СТ	СТ
Radiator Coolant Level	СР	СР	СР	СР	СР	СР	СР
Air Cleaner Bowl Oil (Wet type)	R	R	R	R	R	R	R
Air Cleaner Element (Dry type)	CL	CL	CL	R	CL	CL	CL
Clutch							
Clutch Pedal Free Play	CA	CA	CA	CA	CA	CA	CA
Transmission / Hydraulic							
Transmission Oil	С	С	С	С	R	С	С
Transmission Breather Assy	CL	CL	CL	CL	CL	CL	CL
Operation of Hydraulic Lift	С	С	С	С	С	С	С
Hydraulic Oil Strainer	CL	CL	CL	R	CL	CL	R

/! Safety Starter Switch is to be replaced after every 2000 hours or 4 years, whichever is earlier.

Parameters	50 hrs/ 1st Service	250 hrs/ 2nd Service	500 hrs/ 3rd Service	750 hrs/ 4th Service	1000 hrs/ 5th Service	1250 hrs/ 6th Service	1500 hrs/ 7th Service	
Brakes								
Operation of Brakes	С	С	С	С	С	С	С	
Brake Pedal Free Play	CA	CA	CA	CA	CA	CA	CA	
Steering								
Steering Operation	С	С	С	С	С	С	С	
Front Axle 4x4								
Front Axle Differential Oil	R	С	R	С	R	С	R	
Breather Assy	CL	CL	CL	CL	CL	CL	CL	
Front Axle Pivot	С	С	CA	С	CA	С	CA	
Wheels and Tyres	Wheels and Tyres							
Front Wheel Bolts	СТ	СТ	СТ	СТ	СТ	СТ	СТ	
Rear Wheel Nuts	СТ	СТ	СТ	СТ	СТ	СТ	СТ	
Tyre Inflation Pressure	CA	CA	CA	CA	CA	CA	CA	
Battery								
Battery Electrolyte Level	С	С	С	С	С	С	С	
Battery Terminals	CL	CL	CL	CL	CL	CL	CL	
Electrical								
Functioning of All Gauges & Meters	С	С	С	С	С	С	С	
Functioning of Alternator & Starter	С	С	С	С	С	С	С	

R-Replace, **RR**-Replace if Required, **CT**-Check & Tighten, **C**-Check, **CR**-Clean & Replace, **CA**-Check & Adjust, **CL**-Clean Beyond 1500 hours, repeat the cycle every 250 hours.

IMPORTANT:

- Engine Oil Grade should be selected as per operating Temperature condition.
- Anti freeze should be used in sub zero ambient temperature.
- Clean Air Cleaner system as and when required as per field operating conditions.
- Clutch pedal play should be adjusted as per field operating conditions.

5.2.1 Fuel Tank Filling



Comply with the following instructions when working with the diesel fuel:

- 1. Do not smoke while filling the fuel tank because diesel is flammable liquid and catch fire easily.
- Mixtures of diesel fuel and alcohol are not approved since the resulting lubrication of the fuel injection system is insufficient.
- 3. Clean the area around the filler neck where the fuel is poured.
- 4. Fill the tank at the end of the day to prevent the formation of overnight condensation.
- 5. Never remove the plug or fuel the tractor while the engine is running. Keep control of the pump nozzle whilst the tank is being filled.
- 6. The tank must not be completely filled. Allow space for an increase in volume. If the original tank plug is lost, it must be replaced with an original spare which must be fully tightened.
- 7. Dry up any fuel spill immediately.

5.2.2 Fuel Requisites

It is important to use good quality fuel for the long life & good performance of the engine. The fuels must be clean, well refined and non-corrosive for the fuel system components. Make sure that you use fuel of a known quality and reliable origin.

5.2.3 Fueling

Before you fuel the tractor, clean the zone around the filler neck to prevent foreign bodies from entering the tank. After fuelling, tighten the plug properly.

5.2.4 Fuel Storage

Take all the necessary precautions to ensure that stored fuel does not become polluted with dirt, water or other substances.

Store fuel in black iron cans. Do not store it in galvanized cans as the galvanization treatment would react with the fuel and form compounds that would spoil the injection pump and injectors.

- Store fuel cans away from direct sunlight and slightly tilted, so that any sediment inside is eliminated through the outlet tube.
- To make sludge and water condensation easier to remove; there should be a discharge plug (c), in the lowest point, on the opposite side to the drain tube.
- If the fuel is not filtered from the storage can, use a funnel with the fine gauge mesh over the fuel tank fill plug inlet when fueling.
- Plan your fuel purchases so that summer fuels are not kept for too long and used in the winter.



Fig. 5.2a

Setting up a tank for fuel storage and decanting.

- a. Slope 25%.
- b. Condensation water.
- c. Sludge drain plug.



Fig. 5.2b: Fuel Tank Cap

5.3.1 Checking Engine Oil Level

Before checking the oil level be ensure that tractor is parked on leveled ground. Stop the engine and wait for some time, as all oil should return to oil sump.

Check the oil level by unscrewing dipstick (located at RHS of the Engine). Top up the oil level if the level is below the minimum level mark. Do not over fill than maximum level mark. Oil level should be between maximum and minimum marks (see fig. 5.3a). Recommended grade of engine oil is listed in table 5.3.1.

Model	Recommended Engine Oil Grade
20	SAE-15W40
26	SAE-10W40

Table 5.3.1



Fig. 5.3a: Dipstick marks

5.3.2 Replacement of Oil Filter & Engine Oil

Changing Oil Filter:

 Stop your tractor to the side of road on leveled surface and drain the engine oil in an oil pan after removing the drain plug.
Remove the oil filter by rotating it in anti-clockwise direction by hand or with the filter wrench.

3. Take new oil filter and check it for proper seating of gasket.

4. Apply clean engine oil to gasket on the new oil filter.

5. Install oil filter. When the filter gasket contacts the mounting surface of filter, tighten the new oil filter.

Refer fig. 5.3b & 5.3c for 20 model. Refer fig. 5.3d & 5.3e for 26 model.





Fig. 5.3c

70

Refilling Engine Oil :

1. Re-install the Drain plug and remove the oil filler cap.

2. Fill the engine oil with the specified engine oil to the specified level to sump capacity from oil filler cap.

3. Insert into the oil level gauge guide, then pull out the gauge again.

4. Ensure that oil level should be between the MAX. & MIN. marks on the dipstick. If less, then pour the oil to bring it to specified level.

5. Install the oil filler cap after a refill.

6. Check the oil pan and other parts for oil leakage.

7. Start the engine, allow it to run idle and don't race it immediately.

Refer fig. 5.3b & 5.3c for 20 model. Refer fig. 5.3d & 5.3e for 26 model.



Fig. 5.3d



Fig. 5.3e

5.4 Replacement of Fuel Filter

- 1. Shut down fuel cock.
- 2. Remove the filter by rotating it in anti-clockwise direction by hand or special wrench.
- 3. Take new filter and check it for proper seating of gasket.
- 4. Apply clean engine oil to gasket on the new fuel filter.
- 5. Install fuel filter, when the filter gasket contacts the mounting surface of filter, tighten the filter and ensure that there is no leakage.

Refer fig. 5.4a for 20 model. Refer fig. 5.4b for 26 model.



Fig. 5.4a



Fig. 5.4b

71

5.5 Air Bleeding of Fuel System

After changing the fuel filter the system must be air - bleed in following manner:

- 1. Switch ON the ignition key to start the electric pump till completion of air bleeding process.
- 2. Loosen the vent plug (A) at the top of fuel filter body.
- 3. Tighten the vent plug (A) until the bubble free fuel flows from the air vent plug hole.
- 4. Loosen the vent plug (B) of FIP and allow the air to flow out from the system.
- 5. Tighten the vent plug (B) until the bubble free fuel flows from the return valve.

Refer fig. 5.4a,c for 20 model. Refer fig. 5.4b,d for 26 model.



Fig. 5.4c



Fig. 5.4d

5.6 Radiator

5.6.1 Coolant Level in Radiator (When Hot)

Slowly open the radiator cap (1, fig. 5.6a) up to the safety catch (about 1/3 turn). Wait to allow the steam to escape. Continue opening the cap, press it down firmly to release the safety catch. The level of coolant should just touch the tab located in the filling spout.

If the level has dropped, check the entire cooling system for leakage (radiator, hoses etc.) If there is no leakage, Top up the coolant.

Fill the reserve tank (2, fig. 5.6a) with coolant up to the FULL line mark for coolant Top up.

Coolant is a mixture of water and anti scaling / anti rusting agent in a recommended ratio.

In sub zero temperature climate conditions use Ethylene Glycol antifreeze agent along with water in following ratio (table 5.6.1):

Temperature Range [°] C [[°] F]	0 to -3 [32 to 26.6]	-3 to -8 [26.6 to 17.6]	-8 to - 16 [17.6 to 3.2]	-16 to - 25 [3.2 to -13]	-25 to - 37 [-13 to -34.6]	-37 to - 55 [-34.6 to -67]
Antifreeze (%)	10	20	30	40	50	60



Fig. 5.6a

Table 5.6.1

5.6.2 Radiator Draining & Flushing (When cold)

1. Remove the radiator cap and drain plug (fig. 5.5b).

2. Let the coolant drain out. Close drain cock and plugs. Flush the cooling system with water / Cleaning Solution for 15 minutes, then drain the cleaning solution.

3. Refit the drain plug and refill the coolant (Mixture of water, anti scaling agent, antifreeze).

4. Run the engine with radiator cap open and accelerate 2-3 times and Top up coolant if required.

5. Refit the radiator cap and ensure tightness all the connections for any leakage.

5.6.3 Radiator Fins Cleaning (Fig. 5.6c)

- 1. Check Radiator Fins for holes or cracks for chocking.
- 2. To clean the radiator blow compressed air from engine side to outside.

Cooling system is closed pressurized system so don't

operate the tractor without radiator cap or cap with damaged rubber seals/defective release valve to avoid water loss and



Fig. 5.6b



Fig. 5.6c



Fig. 5.6d

5.7 Inspection of Hoses

5.6.4 Radiator Cap (Fig. 5.6d)

Use genuine radiator cap only.

engine overheating.

Check/Replace Hoses

- Check hoses regularly on every service/before cranking tractor after long idle standing– for leaks, kinks, cuts, tears, rubbing, bulges, corrosion, exposed fabric and other signs of wear and damage.
- · Replace worn or damaged hoses immediately.
- · Replacement hoses are available from your dealer.



NOTE: Refer Maintenance Schedule for Inspection interval of Hoses.



Fig. 5.7 (Ref. Pic. of 26)

5.8 Air Cleaner Maintenance

Air filter discharge valve

Discharge the dust deposits and sediments daily by pressing the rubber valve (4) on the air filter housing (1).

External Cartridge of Dry Air Filter (Fig. 5.8a,b,c)

- (1) Air Filter Housing
- (2) Clamp
- (3) Cover
- (4) Rubber Valve
- (5) Air Cleaner Element

Important Instructions :

Clean the air cleaner element at first 50 hrs & then after every 250 hrs of operation or whenever choke indicator glows on dashboard.

Clean filter element by blowing air from inside. Maximum pressure should not exceed 1.6 bar (23 P.S.I).

Use clean cloth to wipe sealing areas of element.

After replacing new filter element ensure matching of (\blacktriangleleft) mark on cover with the mark (\blacktriangleright) on air filter housing.

Ensure proper seating of filter into housing before latching the cover. Do not use latches on the cover to force the filter into air cleaner that could cause damage to housing and will void the warranty.

Ensure proper seating of all rubber rings. Replace the damaged ones.

Replace air cleaner element after three cleaning operations or at every 750 hours, whichever is earlier.

IMPORTANT: NEVER attempt to clean the filter element with exhaust gas from the engine. NEVER ever use oil on dry filter. NEVER ever use oil, diesel fuel, paraffin or solvents to clean the filter element.



Fig. 5.8a: 20 model



Fig. 5.8b: 26 model



Fig. 5.8c



Fig. 5.8d

5.9 Clutch Pedal

By pressing clutch pedal the motion and power or engine will be disengage from gearbox. Release the clutch pedal slowly for transfer the engine power to gear box.

Method to Check Clutch Pedal Free Play

Press down the clutch pedal and measure the free play of pedal as shown in the figure. The distance should be 25 to 30 mm [0.98 inch to 1.18 inch]. If the distance is less than 25 mm [0.98 inch] or higher than 30 mm [1.18 inch] then get it adjusted.

IMPORTANT: Do not keep foot on clutch pedal while tractor is in running condition. It may cause excessive wear of clutch and clutch falls before its life time.



Fig. 5.9a: 20 model



Fig. 5.9b: 26 model

5.10 Foot Brake Pedals

Use independent brake in the field operations. In field you will turn more sharply by pressing brake pedal for the side wheel on the turn. The pedals must be locked for road use.

Method To Check Brakes Pedal Free Play

Release the hand brake. Uncouple the two pedals. Press down the right hand pedal and measure the free play of pedal as shown in the figure 5.10a & 5.10b.

The distance should be between 25-30 mm [1-1.2 inch] for 20 model and 35-40 mm [1.4-1.6 inch] for 26 model.

If the free play is less than lower limit or higher than upper limit then adjust the both hex nut on actuator tie rod until free play comes between lower and upper limits. Now, press down the left hand pedal. If the values are not equal with the right hand pedal then repeat the same procedure until values come equal.



Difference in the free play will lead to unbalanced brakes, the tractor can slew in the event of violent braking. The wheel on which the brakes are applied locks and the tyre wears out quickly. During Road Operations both the brake Pedals should be locked.



Fig. 5.10a: 20 model



Fig. 5.10b: 26 model

5.11 Steering Cylinder Knuckle Joints (For 26 model)

Have the knuckle joint nuts (1) checked by an authorized service center after the first 50 hours and then at every service.



Fig. 5.11

5.12 Oil Changes in 4WD Front Axle

Oil filling plug (A) is provided on right hand side of the front axle (as shown in fig.). Open the plug and check the oil level. The lower point of the plug should be immersed in the oil.

Front Axle Oil Capacity: 2.7 Litres [0.71 US Gallons] Oil Grade: EP-80



Fig. 5.12

5.13 Oil Changes for Transmission, Rear Final Drives and Power Lift Hydraulic Circuits

NOTE: When draining out and filling oil and checking oil level, take care that the transmission is in horizontal position.

Oil draining

- 1. Lower the lift arms to the ground.
- Remove the plugs located at lower portion of brake housing to make oil draining easier (see fig. 5.13a,b).
- 3.Place vessel under all drain plugs of transmission housing to collect the oil as it drains out.
- 4.Remove the plugs and drain out the oil.
- 5. Clean the plugs and fit back on.



Beware of powerful oil jets. Follow all safety rules.



Fig. 5.13a: 20 model



Fig. 5.13b: 26 model

Filling up the transmission

- 1. Fill up the transmission oil from dipstick plug (1) opening to the maximum level mark on the dipstick.
- 2.Put the gearshift lever in neutral and start the Engine. Let it run on idle until the oil reaches a temperature over 25 °C [77 °F].
- 3. Check that the transmission oil reaches the required level mark on the dipstick.
- 4.If required, fill up to the correct level.

NOTE : Let the oil stabilize before checking its level.

IMPORTANT: See the Lubricants and Fuel chart for the type of oil to be used according to the transmission type.

Refer fig. 5.13c for 20 model. Refer fig. 5.13d for 26 model.

NOTE : If implement used require more quantity of oil, make sure that the transmission contains enough oil for every work condition. Top up as required.

5.14 Recommended Oil grades & Application range (For 26 model)

We recommend use of ELF-2412 / SAE-80W oil grade for transmission and oil brakes .

Refer fig. 5.14 for appropriate oil viscosity according to the ambient temperature.

For 20 model, we recommend use of EP-80 oil grade for transmission oil.



Fig. 5.13c



Fig. 5.13d



Recommended oil viscosity according to air temperature

Fig. 5.14

5.15.1 Cleaning of Suction Strainer (A), Fig. 5.15a (Option in 26 model)

At each service, thoroughly clean suction strainer by washing with light oil or kerosene.

Failure to observe this will result in extensive shortening life of hydraulic system.

Cleaning Procedure of Suction Strainer (fig. 5.15b,c,d):

- (1) Remove all hose warm clips (1).
- (2) Separate the Hose pipes (2) from Strainer Assy.
- (3) Hold the strainer assembly in left hand & remove the wire clip (5) & magnetic strainer (4) from the housing (3) with the help of right hand fingers.
- (4) Unscrew the nut (6) & remove supporting cup (7). After dis-assembling supporting cup remove the sheath (8) having ferrous dust by sliding it with the help of plastic support (10).
- (5) Clean the sheath from ferrous dust with the help of soft cloth and refit the same.
- (6) Assemble the supporting cup & tighten the nut.
- (7) Assemble magnetic strainer in strainer housing and lock it with the wire clip.
- (8) Fix the hose pipes and tighten the hose warm clips.

Replacement: Replace the magnetic strainer at every 750 Hours.

IMPORTANT: Do not dismantle the magnets (9) as these are assembled in polarity sequence and it should not be disturbed (fig. 5.15d).

5.15.1 Cleaning of Suction Strainer Filter (B) (Option in 20 model)

Suction Strainer for 20 model is located at right side of the transmission housing (fig. 5.15e).

At each service, thoroughly clean the strainer by washing with light oil or kerosene.

Failure to observe this will result in extensive shortening life of hydraulic system.







Fig. 5.15d



Fig. 5.15e

5.16 General Maintenance of Electrical System

- Never Patch up the electrical circuits.
- Never replace a blown fuse by a higher capacity fuse. It could cause a fire.
- Never work on components such as the alternator or starter motor when the engine is running.
- Lastly when you are cleaning the tractor and using the pressure spray, take care not to damage the connections on the various electrical cable.

5.17 Battery and its Maintenance

Battery Capacity in 20 model: 12V, 50 Ah Battery Capacity in 26 model: 12V, 65 Ah

Battery Removal Procedure

Battery is located at front of the tractor as shown in the figure, follow the below procedure to access the battery:

1. Open the bonnet.

- 2. Remove fly nut (1, fig. 5.17a) by rotating it anticlockwise.
- 3. Detach the (-)ve & (+)ve terminals (2, 5.17a) respectively.

Check Electrolyte Level

It must be as per the recommendation of battery manufacturer. If required, top up with distilled water just touching the 'Max' mark on the battery (fig. 5.17b). Electrolyte level should never be below 'Min' mark. Never add acid.

Check Carefully Battery Charging

Protect against freezing. Insure that terminals are clean and tight. Check specific gravity of battery using a battery hydrometer (fig. 5.17c). Specific gravity of a fully charged battery is 1.265 ± 0.005 at $27 \degree C$ [80.6 °F].



Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.



Remember to disconnect the cables before you recharge the battery. It is advisable to remove the battery from its location and to recharge it well away from the tractor. The place of battery recharge must be well ventilated.



Fig. 5.17a



Fig. 5.17b



Fig. 5.17c

5.18 Starter Motor

Starter motor is mounted on the left side of the engine. The starting motor rotates the engine crankshaft for starting.

Visually check the starter for damage. If starter is dusty, blow off dust using compressed air.

Note: If defects are found in the starter, contact your dealer.



Fig. 5.18

5.19 Alternator

Alternator is fitted on Left side of engine and generates current which charges battery for healthy electrical back up.

Visually check the alternator for damage. If the alternator is dusty, blow off dust using compressed air.

Remove V-belt, and turn the pulley with hands to make sure it rotates smoothly.

Note: If defects are found in the alternator, contact your dealer.



Fig. 5.19a

5.19.1 Checking V-belt:

- 1. Ensure that V-Belt is free from defects such as wear, cuts or surface separations, otherwise replace with genuine specified belt.
- 2. Inspect belt tension by pushing the belt downward with approx. 98N (10kgf) (22lbf) force midway between pulleys. If the deflection is 10 to 12mm [0.39 to 0.47 in], the tension is correct. If the tension out of the specified value, adjust belt tension.

5.19.2 Adjusting V-belt tension:

- 1. Loose all retaining bolts of the alternator and adjusting plate.
- 2. Insert a bar between the alternator and cylinder block and use leverage to move that alternator to have proper v-belt tension.
- 3. While V-belt tension is appropriate, retighten all the retaining bolts of the alternator and adjusting plate.



Fig. 5.19b



Fig. 5.19c

5.20 Fuses in Fuse Box (Fig. 5.20a, b, c)

Fuses against short circuits and excessive power draw protect the tractor's electrical system. The number of the fuses in the electrical system depends on the tractor model.

NOTE : Before replacing a blown fuse with a new, equivalent ohm, the cause that lead to the fault should be ascertained and removed.

Front Work Lamp -	High Beam -
15 Amp	15 Amp
Rear Work Lamp -	Low Beam -
15 Amp	15 Amp
Plough Lamp -	Parking Light -
10 Amp	10 Amp
Brakes -	Horn -
10 Amp	10 Amp
Flasher -	Thermostat -
15 Amp	30 Amp
Stereo -	Mobile Socket -
10 Amp	10 Amp
Wiper - 10 Amp	

Fig. 5.20a: Fuse Box for 20 model

Front Work Lamp -	High Beam - 15
15 Amp	Amp
Rear Work Lamp -	Low Beam -
15 Amp	15 Amp
Plough Lamp -	Parking Light -
30 Amp	10 Amp
Brakes -	Horn -
10 Amp	10 Amp
Flasher -	Glow Plug -
15 Amp	40 Amp
Revolving Light -	Mobile Socket -
10 Amp	10 Amp
Wiper - 10 Amp	Controller Timer- 20 Amp

Fig. 5.20c: Fuse Box for 26 model

5.21 Long Idle Period

Take the following precautionary measures when your tractor is not going to be used for a long period of time.

- Park the tractor in dry sheltered place.
- Drain the coolant from the radiator and engine.
- · Grease all points provided with grease nipples.
- Remove the injectors and squirt a small quantity of engine oil into the cylinders. Turn the engine over by hand, and then fit the injectors back in place.
- Generally clean the tractor .particularly the bodywork components. Protect the painted parts by applying silicon wax and the unpainted metal parts by applying protective lubricant. Park the tractor in a dry, sheltered and possibly ventilated place.
- Make sure that all the controls are in neutral (including he electric switches and parking brake controls).
- Remove the ignition key from ignition switch.
- Make sure that the cylinder stems (of the power steering, power lift system, etc) are positioned.
- Empty the fuel tank and fill with it with new diesel fuel until the maximum level is reached.
- Remove the battery, clean the cover and spread Vaseline on the terminal and terminal caps. Now connect the battery in the ventilated place where the temperature is not liable to drop below 10 and where it is not exposed to direct sunlight.
- Check the battery charge with a voltmeter as described in the battery part of this section Recharge if it is necessary.
- Place stands or other supports under the axles in order to take the weight off the wheels. When the tractor is raised in this way, it is advisable to deflate the tyres. If this is not possible, the tire pressure must be periodically checked.
- Cover the tractor with a tarpaulin (not plastic or waterproof).



At the end of the idle period. When you start the engine again, pay particular attention to the instruction about starting engine in the operation chapter.

5.22.1 Greasing Points in 20 model

- 1. Center Pin
- 2. Drag Links
- 3. Clutch Actuating Shaft
- 4. Brake Pedal Shaft

- 1 Point
- 4 Points
- 2 Points
- 2 Points



1. Center Pin



2. Drag Links (LH& RH)



3. C.A. Shaft



4. Brake Pedal Shaft

5.22.2 Greasing Points in 26 model

- 1. Clutch Actuator Shaft (LH and RH)
- 2. Brake pedal shaft (LH and RH)
- 3. 4WD Mechanism
- 4. Propeller shaft UG joints (Front and Rear)
- 5. Power Steering Cylinder Knuckle Joint (On steering arm double side)
- 6. Lift Rods (LH and RH)
- 7. Front Axle Pivot Pin
- 8. Power Steering Cylinder

- 2 Points - 1 Point

- 2 Points

- 2 Points
- 1 Point
- 2 Points
- 1 Point
- 1 Point







2. Brake pedal shaft



3. 4WD Mechanism



4. Propeller Shaft UG Joint



7. Front Axle Pivot Pin



5. Power Steering Cylinder (On steering arm double side)



6. Lift Rods



8. Power Steering Cylinder (On mounting bracket)

5.23 Jack Up the Tractor - Lifting Points

The illustrations show the recommended lifting points for jacking up the tractor. Use a stable lifting jack with sufficient lifting force.

- A- Raise Right End of Axle, e.g. to Remove Right Front Wheel.
- B- Raise Center of Axle (Use Wooden Wedges to Prevent Axle from Tilting).
- C- Raise Left End of Axle, e.g. to Remove Left Front Wheel.
- D Raise Rear of Tractor, e.g. to Remove Rear Wheel



- Use approved lifting equipment only.
- Jack up tractor on firm, level ground only.
 - Before doing any further work on the tractor, first secure it using suitable support stands.
- Refer fig. 5.23a, 5.23b for 20 model. Refer fig. 5.23c, 5.23d for 26 model.



Fig. 5.23a - Raise front of tractor



Fig. 5.23b - Raise rear of tractor



Fig. 5.23c - Raise front of tractor



Fig. 5.23d - Raise rear of tractor

85

5.24 Oil and Lubrication Chart

Aggregate	Capacity	Recommended Grade		
Engine Oil	20: 3.6 Litres [0.95 US Gallons] 26 : 4.2 Litres [1.11 US Gallons]	20 : SAE-15W40 26 : SAE-10W40		
Gearbox and Rear Axle	20: 16 Litres [4.23 US Gallons]26: 18 Litres [4.75 US Gallons]	20: EP-80 26: ELF-2412		
Front Axle	2.7 Litres [0.71 US Gallons]	EP-80		
Fuel	29 ± 3 Litres [7.66 ± 0.79 US Gallons]	High Speed Diesel conforming to IS: 1460-2000 Density 0.840 g/cm ²		

Table 5.24



87

